



Product Name : " SHOE SHINE MACHINE "
Product Code : " CKE 34 "



Description :

SHOE SHINE MACHINE:-

Motor 220V AC.900rpm.An infrared system is used to automatically trigger off the shoeshine machine as soon as the shoe is inserted into it. The softbrush starts rotating automatically removing the dust from the shoe .The shoe is pressed against the nozzle of the cream polish dispenser. The shoe id then held against the black or brown brush as per the shining brightly.